

GREASE STICK PIN

GREASE TOP
AND BOTTOM
OF L BOOM

GREASE SADDLE SIDES

GREASE SIDES
OF L BOOM

GREASE LOWER UNIT

GREASE JAW PIN

**UNIT SHOULD BE GREASE EVERY
OTHER WEEK DURING NORMAL USE**

GREASE FOLD PIN

GREASE KING PIN

GREASE JAW PIN

